



World-wide Headquarters:
3000 North 29th Ct., Hollywood, Florida, USA,
FL 33020
Tel: +1-954-929-1115 Fax: +1-954-929-5560
www.chauvetlighting.com

User Guide

Egg Strobe

Model: CH-766

Power Supply: AC 100~130V 60Hz or 230 ~ 250v 50Hz

Bulb: Xenon flashtube 5W

Dimensions: 127 x 76.2 x 76.2mm / 5 x 3 x 3in

Weight: 0.2kg / .37lbs



PRODUCT DESCRIPTION:

- 5W egg strobe
- Screw In Base
- Adjustable flash control knob (1-12 flashes per second)
- Plastic case
- Light weight
- Add fun and sparkle to your show.

GENERAL FUNCTIONS:

1. Power input: AC 100~130V/60Hz or 230 ~ 250v 50Hz
2. Speed knob: To adjust the flash speed.

CAUTION:

- Always remember to unscrew the unit from the main power before any service is done.
- Do not open the unit; there are no serviceable parts inside.
- To prevent fire or shock hazard, do not expose the unit to the rain or moisture.

Contact Chauvet

USA

Technical Assistance: 1-800-762-1084 (954) 929-1115

E-Mail tech@chauvetlighting.com