



## **COLORcoaster™**

### **Introduction**

Congratulations on the purchase of your new CHAUVET lighting effect. We are confident you will enjoy many trouble free hours with this unit. To assist with the care and use of the product we have prepared this short guide.

### **Operation**

This lighting effect has been designed to function on 3 "AA" batteries or with the optional LED-CDPS power adapter, 5VDC 800 mA. If the power adapter is used, then up to 12 COLORcoaster maybe linked together using the cable supplied with each unit.

On the bottom of each COLORcoaster is a 3 position switch, on - off - 30 minutes. Simply move the switch to the desired setting. The COLORcoaster is activated when the object to be illuminated is placed on the unit.

In order to function properly, the COLORcoaster must be placed on a hard flat surface. This will ensure that the pressure switch on the bottom is fully depressed. When activated the LEDs will light in a constantly changing pattern, creating a myriad of colors.

### **Servicing**

Do not open unit. There are no serviceable parts inside. If you have any difficulties, please contact CHAUVET.

### **Specifications**

Power: 3 x "AA" batteries  
Optional 5VDC 800mA Power Adapter

Light Source: High Power LED's  
2 x Red  
1 x Blue  
1 x Yellow

Weight: 3.2 oz

Dimensions: 3.75 x 3.75 x .87 in

**CHAUVET**  
3000 North 29<sup>th</sup> ct.  
Hollywood Florida 33020 USA  
Tel: + 1-954-929-1115  
Fax: + 1-954-929-5560

**[www.ChauvetLighting.com](http://www.ChauvetLighting.com)**