
If you like this product then why not take a look at some of the other items available from



EXCB-25

Extension Cable for SF-8000 and SF-9000 controllers.
Can be linked to extend.







Remember if you're looking for lights – Ask for CHAUVET!



Relay Pack

SR-8

Users Guide

Please read these instructions carefully before use

World-wide Headquarters:

3000 North 29th Ct., Hollywood, Florida, USA, FL 33020 Tel: +1-954-929-1115 Fax: +1-954-929-5560

www.ChauvetLighting.com



Congratulations on the purchase of your new CHAUVET lighting controller. We are confident you will enjoy many trouble free hours with this unit. To assist with the care and use of the product we have prepared this short guide.

Operation

This lighting controller has been designed to function on a mains power supply of either 120V~60Hz or 230V~50Hz and has been fitted with a suitable power plug for use with your local voltage. Check the label on the unit and the power plug for the correct voltage.

The unit has been designed to be used in exclusively with the CHAUVET SF-8005 Controller System and the SF-9005 Chasing Timer Control.

The SR-8 Relay Pack features 8 switched power sockets (that correspond to channel 1-8 on the Switch Panel of the SF-8000/9000), and one unswitched power socket for "constant on" item. An unlimited amount of SR-8 Relay Packs may be run off one switch panel. To do this simply connect an EXCB-25 extension cable from the "line out" on one SR-8 relay pack to the "line in" on another SR-8 relay pack (fig. 1). Maximum load per SR-8 relay pack is 15-amps or 1800 watts.

For your protection the relay pack has been fitted with a 15A circuit breaker which will disconnect the main power supply to the outlets should you either overload the unit or if there is a pwer surge. In such circumstances it is necessary to press the Reset Button (fig. 1) to activate the power to the controller.

Installation / Mounting

The SR-8 Relay Pack may be used either mounted on a level surface or to a lighting stand/truss. It is recommended that, for safety purposes, your relay pack be properly mounted using the mounting holes and safety cable. CHAUVET offers a range of items which are ideal for safe mounting.

Optional Accessories

Optional accessories available from CHAUVET for your new Relay Pack include 25 foot extension cable (EXCB-25).

Cleaning

The body of the unit may be cleaned with a soft damp cloth. We recommend internal cleaning be carried out by a fully qualified technician.

Maintenance & Servicing

Work on internal parts should be carried out by a qualified technician. Removal of any covers is considered a breach of warranty and will not be covered under any such agreement unless authorized first by the company.

Troubleshooting

- If the unit is not functional check main power supply is 'on' and reset circuit breaker.
- If the unit continually trips the circuit breaker check the rating of the load and wiring. If after trying this solution you still have a problem contact your dealer or CHAUVET.

Caution

No user serviceable parts inside, please refer to CHAUVET for service.

Power Connections

The unit is supplied with a power plug appropriate to its voltage and destination. Should any other connections be required they must be carried out with the following configuration.

Earth = Green/Yellow cable Neutral = Blue cable Live = Brown cable

In the USA & Europe, it is required that all plugs are 3-pin type i.e. with Earth/Ground connection. In the UK, it is required that all mains plugs are fitted with 13A fuses.

Technical Specifications

Power	120V~60Hz AC	230V~50Hz AC	
Load Capacity	15A	15A (with suitable connector) 13A (with UK mains plug)	
Circuit Breaker	15A Reset Switch	15A Reset Switch	
Power Outlets	8 x 120V (10A) 3-pin female	8 x 230V (10A) 3-pin IEC female	
Dimensions	396mm x 92mm x 41mm / 15.6in x 3.6in x 1.6in		
Weight	1.4kg / 3.0lbs		

User Information	Please	complete f	or your records)
Date Purchased:	1	1	Serial No:
Dealer Stamp:			Model: SR-8 RELAY PACK
		1882	