

Troubleshooting

- If the unit is not functional – check the main power supply and for a blown fuse.
- If the unit is functional but the lamp is not on - lamp may need replacing.
- If the unit is not flashing to the music, check the sound sensitivity adjustment.
- If after trying this solution you still have a problem, contact CHAUVET.

Contact Chauvet

USA

Technical Assistance: 1-800-762-1084 (954) 929-1115
E-Mail tech@chauvetlighting.com

Caution

Do not touch unit or lamps while its hot.
Never put any objects through the front of the unit.
No user serviceable parts inside, please refer to CHAUVET for service.

Power Connections

The unit is supplied with a power plug appropriate for its voltage and destination. Should any other connections be required they must be carried out with the following configuration.

Earth = Green/Yellow cable
Neutral = Blue cable
Live = Brown cable

In the USA & Europe, it is required that all plugs are 3-pin type i.e. with Earth/Ground connection.
In the UK, it is required that all mains plugs are fitted with 5A fuses.

Technical Specifications

Power	120V~60Hz AC	230V~50Hz AC
Lamp	120V 35w Part No WSB	230V 35w Part No WSB2
Dimensions	200 x 150 x 190mm / 8 x 6 x 7.5in	200 x 150 x 190mm / 8 x 6 x 7.5in
Weight	. 45kg / 1lbs	. 45kg / 1lbs

User Information (Please complete for your records)

Date Purchased: / /

Serial No: _____

Dealer Stamp:

Model: **ST-1000S Techno Strobe 1000S**



Techno Strobe™ 1000S

ST-1000S

User Guide

Please read these instructions carefully before use

World-wide Headquarters:

3000 North 29th Ct.
Hollywood, Florida, USA 33020
Tel: +1-954-929-1115 Fax: +1-954-929-5560

www.ChauvetLighting.com