

JEM SMOKE MACHINE COMPANY LTD VALE ROAD INDUSTRIAL ESTATE, BOSTON ROAD, SPILSBY, LINCS, PE23 5HE

TEL: (01790) 754050, FAX: (01790) 754051

JEM 428 CONTROLLER **PROGRAMMING INSTRUCTIONS**

ISSUE #2 - DECEMBER 1996

A) SWITCH ON UNIT

B) SELECT MEMORY BANK TO BE PROGRAMMED

C) TURN AUTHORITY KEY TO ON POSITION

D) PRESS PROG/RUN BUTTON (PROG/RUN AND HOLD FOG LED'S SHOULD LIGHT)

E) PRESS RESET BUTTON (CHECK PROG TIME COUNTER AT ZERO)

F) SELECT CHANNELS TO FIRE FOR THE FIRST SECOND OF PROGRAMME :

E.G.: TO FIRE CHANNELS 1 AND 2 ENSURE MEMORY LED'S FOR CHANNEL 1 AND 2 ARE LIT. PRESS ONCE TO TURN ON AND ONCE MORE TO TURN OFF.

G) PRESS ENTER TO STORE FIRST SECOND. TIME DISPLAY WILL ADVANCE BY ONE.

H) REPEAT STEPS F + G FOR THE FOLLOWING ONE SECOND TIME STEPS.

NOTE MAXIMUM NUMBER OF STEPS (SECONDS) IS 254 PER BANK. 8 BANKS ARE AVAILABLE WHICH CAN BE RUN THROUGH IN TURN (AUTORUN) GIVING OVER HALF AN HOUR OF TIME WHICH THEN REPEATS.

I) ONCE REQUIRED NUMBER OF STEPS HAVE BEEN ENTERED TURN AUTHORITY KEY TO OFF TO BEGIN CYCLE.

J) PRESS HOLD FOG BUTTON TO TURN LED OFF AND START FOG.