# LRG-55 Scorpion™ 55 RG







CHAUVET, 3000 N 29<sup>th</sup> Ct, Hollywood, FL 33020 U.S.A (800) 762-1084 – (954) 929-1115 FAX (954) 929-5560 www.chauvetlighting.com

# **TABLE OF CONTENT**

| BEFORE YOU BEGIN   | 3  |
|--|--|
| WHAT IS INCLUDED UNPACKING INSTRUCTIONS AC POWER SAFETY INSTRUCTIONS.  | 3<br>3   |
| INTRODUCTION   | 5  |
| FEATURES DMX CHANNEL SUMMARY PRODUCT OVERVIEW GENERAL INSTRUCTIONS.  | 5<br>6   |
| COMPLIANCE STATEMENT   | 8  |
| LASER SAFETY AND COMPLIANCE INFORMATION PROPER USAGE   |  |
| CONTROL & FUNCTION   | 9  |
| DIPSWITCH CHART  DMX MODE  Setting the starting address  OPERATION  Stand-Alone Operation (Sound_Active, Auto Mode):  Master-Slave Operation (Master_Sound, Master_Auto):  Universal DMX Control (DMX Mode):  TROUBLE SHOOTING.                        | .10<br>.11<br>.11<br>.11<br>.12                      |
| APPENDIX   | .13  |
| DMX PRIMER Fixture Linking.  DMX QUICK REFERENCE CHART  DMX CHANNEL VALUES  TROUBLE SHOOTING  DYNAMIC PATTERNS & DMX VALUES  STATIC PATTERNS & DMX VALUES  GENERAL MAINTENANCE  RETURNS PROCEDURE  CLAIMS  TECHNICAL SPECIFICATIONS  TECHNICAL SUPPORT | .13<br>.14<br>.15<br>.15<br>.16<br>.17<br>.18<br>.18 |
| LECTINICAL SUPPORT   | . 19   |

# **BEFORE YOU BEGIN**

#### What is included

- > 1 x Scorpion™ 55 RG
- Warranty Card

- User Manual
- Power cord

### **Unpacking Instructions**

Immediately upon receiving a fixture, carefully unpack the carton, check the contents to ensure that all parts are present, and have been received in good condition. Notify the shipper immediately and retain packing material for inspection if any parts appear damaged from shipping or the carton itself shows signs of mishandling. Save the carton and all packing materials. In the event that a fixture must be returned to the factory, it is important that the fixture be returned in the original factory box and packing.

#### **AC Power**

To determine the power requirements for a particular fixture, see the label affixed to the back plate of the fixture or refer to the fixture's specifications chart. A fixture's listed current rating is its average current draw under normal conditions. All fixtures must be powered directly off a switched circuit and cannot be run off a rheostat (variable resistor) or dimmer circuit, even if the rheostat or dimmer channel is used solely for a 0% to 100% switch. Before applying power to a

channel is used solely for a 0% to 100% switch. Before applying power to a fixture, check that the source voltage matches the fixture's requirement.

Figure 1 - AC Voltage Switch

Check the fixture or device carefully to make sure that if a voltage selection switch exists that it is set to the correct line voltage you will use.



Verify that the power select switch on your unit matches the line voltage applied. All fixtures must be connected to circuits with a suitable Earth Ground.



Not all fixtures have a voltage select switch. Please be sure to connect to the proper voltage.



CAUTION: Do not use Optical Instruments such as binoculars, telescopes, or extreme prescription glasses to view the laser. These instruments may intensify the laser power and cause serious injury to your eyes

### **Safety Instructions**



# Please read these instructions carefully, which includes important information about the installation, usage and maintenance?

- Please keep this User Guide for future consultation. If you sell the unit to another user, be sure that
  they also receive this instruction booklet.
- Always make sure that you are connecting to the proper voltage and that the line voltage you are connecting to is not higher than that stated on decal or rear panel of the fixture.
- This product is intended for indoor use only!
- To prevent risk of fire or shock, do not expose fixture to rain or moisture. Make sure there are no flammable materials close to the unit while operating.
- The unit must be installed in a location with adequate ventilation, at least 50cm from adjacent surfaces. Be sure that no ventilation slots are blocked.
- Always disconnect from power source before servicing or replacing lamp or fuse and be sure to replace with same lamp source.
- Secure fixture to fastening device using a safety chain. Never carry the fixture solely by its head. Use
  its carrying handles.
- Maximum ambient temperature is Ta: 35°. Do not operate fixture at temperatures higher than this.
- In the event of serious operating problem, stop using the unit immediately. Never try to repair the unit by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. Always use the same type spare parts.
- Don't connect the device to a dimmer pack.
- Make sure power cord is never crimped or damaged.
- Never disconnect power cord by pulling or tugging on the cord.
- Avoid direct eye exposure to lamp while it is on.

#### Caution!

There are no user serviceable parts inside the unit. Do not open the housing or attempt any repairs yourself. In the unlikely event your unit may require service, please contact CHAUVET.

# INTRODUCTION

You may notice that both the red and green beams coming out of the projector are larger than the 4.95mW projectors. There is a very distinct reason for this. Unlike 4.95mW projectors the output of the CHAUVET laser projectors with Fatbeam<sup>TM</sup> technology inside outputs <20mW for each beam. Normally outputs greater than 4.95mW require a variance from the FDA. This product has been designed to meet a special classification of ClassIIIR. Under this classification with the Fatbeam<sup>TM</sup> technology the acceptable energy levels (AEL) have been met. Therefore the maximum potential exposure to the unaided eye is less than 4.95mW for a static beam. Additionally the (MPE) or Maximum Permissible Exposure with this product is below acceptable levels for human ocular or tissue exposure.

#### **Features**

#### **CONTROL FEATURES**

- 8-channel DMX controlled green and red laser
- 41 Dynamic, 50 Static patterns, laser off & sound active mode
  - Scan and speed adjustment yields 500 laser effects
  - 44 patterns in sound active mode
  - 48 patterns in auto mode
- X and Y position adjustment of laser effect
  - X moves lasers in opposite movements
  - Y moves lasers in unison
- · Dynamic Scan speed adjust
- Dynamic pattern speed adjust
- Static pattern size adjust
- Laser color selection; red, green or both red & green

#### **FEATURES**

- Dual 10mW Fatbeam<sup>™</sup> Laser technology produces 10-14mm beam which complies with IEC Safety Standards under ClassIIIR
- Operating modes; Auto, Sound Active, Master/Slave & DMX
- · Safety cover for scanner mirrors
- Sound sensitivity control

- Sound activated via DMX
- Scanning motors (micro stepping)
- Rugged construction
- Fan cooled

## **DMX Channel Summary**

| CHANNEL | FUNCTION               |
|---------|------------------------|
| 1       | Mode                   |
| 2       | Pattern Selection      |
| 3       | X Position             |
| 4       | Y Position             |
| 5       | Scan speed             |
| 6       | Dynamic Pattern select |
| 7       | Static Pattern size    |
| 8       | Color                  |


### **Product Overview**



AVOID EXPOSURE
Visible and/or Invisible
LASER RADIATION EMITTED
FROM THIS APERTURE

#### DANGER: Laser Radiation emitted from this aperture.

Before connecting the unit to AC power, make certain that the front aperture is pointed away from you or others.



#### **AC Power Connection:**

The unit is supplied with a power plug appropriate to its voltage and destination. Should any other connections be required they must be carried out with the following configuration.

Earth = Green/Yellow cable Neutral = Blue cable Live = Brown cable

#### **General Instructions**

Please read carefully and thoroughly the contents of this manual before operating the Laser system. These instructions contain important safety information regarding the use and maintenance of this system. Please keep this manual for future reference.

- Every unit has been thoroughly tested and has been shipped in perfect operating condition.
- Check the shipping carton for damage that may have occurred during shipping.
- If the carton appears to be damaged carefully inspect your unit for any damage.
- Be sure all equipment necessary to operate the system gas arrived intact.
- In the event that damage has been found or parts are missing, please contact CHAUVET customer support for further instructions.
- Please do not return the unit to your dealer without first contacting CHAUVET customer support.

#### Notice!

- Please insure the power supply has good connect with ground before operating the unit in order to prevent electrical shock.
- This system is intended to only be operated indoors. Avoid any direct contact with water, and make certain the unit is firmly mounted.
- 3) Ensure the operating temperature is within the specified normal range of 18~30° C.
- 4) Prolonged operation shortens the life of the laser device.
- 5) The system over a long period of time may build up dust and other contaminants on the scanner optics and or the aperture window.
- 6) Do not remove any of the laser safety warning labels, manufacturing label, and warranty labels. If the warranty labels are broken the warranty will be voided.
- 7) Please contact us if you experience any problems with this unit.
- NO USER SERVICABLE PARTS INSIDE: Warranty Void if Warranty Seals are missing or appear tampered with.



9) Please do not discard the shipping materials. In the event you must return the unit please do so in the original factory packaging to avoid further damage.

# COMPLIANCE STATEMENT

Your LRG-55 complies with FDA/CDRH 21CFR1040 and Laser Notice 50 as well as IEC 60825-1:2003. Due to a unique optic design, this product does not exceed output powers that exceed its classification and output levels government agencies have determined to be appropriate for the products function.

### Laser Safety and Compliance Information

This product is manufactured to comply with the IEC 60825-1 and in accordance with U.S. Food and Drug Administrations (FDA) Standards listed under FDA Document 21 CFR 1040 and subsequent laser notices.

Product Classification and Manufacturing Label Identification

| Laser Classification         | Class IIIa                            |
|------------------------------|---------------------------------------|
| Laser Medium                 | DPSS YVO4 532nm / Diode 650nm         |
| Cooling                      | Fan Cooled                            |
| Output                       | Dual <20mW                            |
| Beam Diameter at aperture    | 10 – 14mm                             |
| Beam Divergence              | Optically adjusted for compliance     |
| Radiant Exposure at Aperture | <4.95mW (7mm Human Limiting Aperture) |


There is only one laser aperture on this product.



DANGER - Visible and invisible Laser radiation when open. Avoid Direct Eye or Skin Exposure

**CAUTION: AVOID EXPOSURE TO BEAM: Avoid** direct eye contact with laser light. Never intentionally

expose your eyes or others to direct laser radiation.



Non-Interlocked Housing Warning Labels. This unit contains an embedded laser device that exceeds the output of the intended class internally. Exposure to unsafe levels of laser radiation when opened.




Additionally there are no user serviceable parts inside. Tampering or removing warranty seals will void your products limited warranty.

#### **CAUTION:**

The use of corrective eye wear or optics for viewing at distances such as telescopes or binoculars within a distance of 100mm may pose an eye hazard.

This unit has been designed to be hung. It is recommended that, for safety purposes, your lighting effect are properly mounted using a suitable hanging clamp and safety cable. **CHAUVET** offers a range of items, which are ideal for safe mounting.

It is the responsibility of the manufacturer to provide useful instruction on the proper use of this product. According to FDA Regulations you should operate the product in the fashion illustrated below.



CAUTION: Use of controls, adjustments, or performance of procedures other than what is specified herein may result in hazardous radiation exposure

# **CONTROL & FUNCTION**

This unit uses dipswitches to assign a units function, DMX address and DMX MODE of function. Each dipswitch represents a binary value.

## **Dipswitch Chart**

#### 0=OFF 1=ON X=0FF or ON

|                 |   |   |   | FUNCTION |   |   |   |   |    |    |    |              |
|-----------------|---|---|---|----------|---|---|---|---|----|----|----|--------------|
| 1               | 2 | 3 | 4 | 5        | 6 | 7 | 8 | 9 | 10 | 11 | 12 |              |
| Х               | Х | Х | Х | Χ        | Χ | Х | Х | Х | 0  | 0  | 0  | SOUND ACTIVE |
| Х               | Х | Х | Х | Χ        | Χ | Х | Χ | Х | 0  | 0  | 1  | AUTO MODE    |
| Х               | Х | Х | Х | Х        | Х | Х | Х | Х | 0  | 1  | 0  | MASTER_SOUND |
| Х               | Χ | Χ | Χ | Х        | Χ | Х | Χ | Х | 0  | 1  | 1  | MASTER_AUTO  |
| Х               | Х | Х | Х | Χ        | Χ | Х | Χ | Х | 1  | 0  | 0  | SLAVE        |
| SET DMX ADDRESS |   |   |   |          |   |   |   |   | 1  | 0  | 1  | DMX MODE     |
| Х               | Х | Х | Х | Χ        | Χ | Х | Χ | Χ | 1  | 1  | 0  | TEST MODE    |

Function chart

Dipswitches #10,#11,and #12 is set system function, from #1 to #9 is set DMX512 address in DMX MODE.

In this mode you will be able to control each individual trait of the fixture independently. The LRG-55 occupies 8 channels of DMX control. For detailed listing of the DMX channel values refer to the Appendix section.

#### SETTING THE STARTING ADDRESS

This DMX mode enables the use of a universal DMX controller device. Each fixture requires a "start address" from 1 to 511. A fixture requiring one or more channels for control begins to read the data on the channel indicated by the start address. For example, a fixture that occupies or uses 6 channels of DMX and was addressed to start on DMX channel 100, would read data from channels: 100, 101, 102, 103, 104, and 105. Choose start addresses so that the channels used do not overlap and notate the start address selected for future reference.

If this is your first time addressing a fixture using the DMX-512 control protocol than I suggest jumping to the Appendix Section and read the heading "DMX Primer". It contains very useful information that will help you understand its use.

Set the start address using the group of DIP switches located usually on bottom of the fixture. Each dip switch has an associated value. Adding the value of each switch in the ON position will provide the start address. Determining which switches to toggle ON given a specific start address can be accomplished in the following manner. By subtracting the largest switch value possible from the selected start address which does not cause a negative number.

#### **EXAMPLE STARTING ADDRESS**

| Address 10                                | 164<br>16<br>8<br>4<br>4<br>1  | 256 DI                | IP                           |
|---|--|-----------------------|------------------------------|
| Pin # 4 = 8<br>Pin # 2 = 2<br>Total = 10  | 1 2 3 4 5 6 7  | 8 9 10 11             | 12                           |
| Address 24                                | 16<br>16<br>16<br>12<br>12   | 256 D                 | IP                           |
| Pin # 5 = 16<br>Pin # 4 = 8<br>Total = 24 | 1 2 3 4 5 6 7<br>ON OFF  | 8 9 10 11             | 12                           |
| Resolving address using simple math.      | 233 – (128) = 105, Turn ON Dip # 8<br>105 – (64) = 41, Turn ON Dip # 7   | DIP SWITCH            | (DMX VALUE)                  |
| Address 233                               | 41 – (32) = 9, Turn ON Dip # 6<br>9 – (8) = 1, Turn ON Dip # 4<br>1 – (1) = 0, Turn ON Dip # 1                           | 1<br>2<br>3<br>4      | 1<br>2<br>4<br>8             |
|   | You will most likely use the first available number which maybe number 1. This number was selected for example purposes. | 5<br>6<br>7<br>8<br>9 | 16<br>32<br>64<br>128<br>256 |

#### Stand-Alone Operation (Sound\_Active, Auto Mode):

This mode allows a single unit to run to the beat of the music, or the unit will auto change in Auto Mode.


1) Set dipswitches position to Sound Active or Auto Mode.


Mode Dipswitches

Sound Active 10 = Off, 11 = Off, 12 = Off Auto Mode 10 = Off, 11 = Off, 12 = On

- The unit will react to the low frequencies of music via the internal microphone in Sound Active mode, or the unit will auto change in Auto Mode.
- Use the audio sensitivity knob on the back of the unit to make the unit more or less sensitive in Sound Active.







N: SOUND/AUDIO

2: SOUND/AUTO

Master-Slave Operation (Master Sound, Master Auto):

This mode will allow you to link up to 32 units together without controller.

- Use standard XLR DMX cable to daisy chain your units together via the XLR connector on the rear of the units. For longer cable runs we suggest a terminator on the last fixture.
- Choose a unit to function as Master mode. Turn dipswitches to the Master position on the unit. The unit must be first unit in line. Then simply chain the units together using XLR cable.


Mode Dipswitches

Master Sound 10 = Off, 11 = On, 12 = Off Master Auto 10 = Off, 11 = On, 12 = On

3) Turn switch to the Slave position on the slave units, and they will react the same as the Master.

Mode Dipswitches

Slave 10 = On, 11 = Off, 12 = Off



#### Universal DMX Control (DMX Mode):


This mode allows you to use a universal DMX-512 controller to control lasers operation and effects.

 To control your fixture in DMX Mode use standard XLR DMX cable to daisy chain your units together via the XLR connector on the rear of the units. For long cable runs we suggest a terminator at the last fixture.

Mode Dipswitches

DMX mode 10 = On, 11 = Off, 12 = On

- 2) Assign a DMX address to the unit by following the dipswitch chart.
- 3) Use DMX controller to control your units.



Note! System doesn't use DMX controller in Master-Slave Mode. System may not set to two Master units in Master-Slave Mode.

### **Trouble Shooting**

- If the power supply indicator does not light up and the laser does not work, please check if the power supply and the corresponding parts have the right input electric current.
- If it is in stand-alone mode operation, the power supply indicator is lit and the laser is not working, please check if the operation system is set up in Master/Slave mode.
- 3) If it is in Master/Slave mode, Slave mode is exceptional, please check as below:
  - A. Make sure to set up Master mode for just one unit and the others are set in slave mode.
  - B. Make sure to control the unit with DMX controller.
  - C. Make sure to take a good quality power cord and connection.
- 4) If the unit is in DMX mode, the laser cannot be controlled by the DMX controller, and the DMX signal indicator is not illuminated please check as below:
  - A. Make sure to set up the DMX mode.
  - B. Make sure to have a good connection.
- 5) If it is in DMX mode, the laser is cannot be controlled by the DMX controller but the DMX signal indicator flashes, please make sure the DMX controller and the laser have the same DMX Address.
- 6) If the no laser outputs from the projector please restart the AC power by turning off the AC switch and leaving off for 15 seconds and then turning the switch back to the on position.
- 7) If the test pattern is not in the proper position restart the AC power by turning off the AC switch and leaving off for 15 seconds and then turning the switch back to the on position.

After trying the above solution you still have a problem, please contact CHAUVET.


# **APPFNDIX**

#### **DMX Primer**

There are 512 channels in a DMX-512 connection. Channels may be assigned in any manner. A fixture capable of receiving DMX 512 will require one or a number of sequential channels. The user must assign a starting address on the fixture that indicates the first channel reserved in the controller. There are many different types of DMX controllable fixtures and they all may vary in the total number of channels required. Choosing a start address should be planned in advance. Channels should never overlap. If they do, this will result in erratic operation of the fixtures whose starting address is set incorrectly. You can however, control multiple fixtures of the same type using the same starting address as long as the intended result is that of unison movement or operation. In other words, the fixtures will be slaved together and all respond exactly the same.

DMX fixtures are designed to receive data through a serial Daisy Chain. A Daisy Chain connection is where the DATA OUT of one fixture connects to the DATA IN of the next fixture. The order in which the fixtures are connected is not important and has no effect on how a controller communicates to each fixture. Use an order that provides for the easiest and most direct cabling. Connect fixtures using shielded two conductor twisted pair cable with three pin XLR male to female connectors. The shield connection is pin 1, while pin 2 is Data Negative (S-) and pin 3 is Data positive (S+). CHAUVET carries 3-pin XLR DMX compliant cables, DMX-10 (33'), DMX-4.5 (15') and DMX-1.5 (5')

#### **FIXTURE LINKING**



#### Note!

If you use a controller with a 5 pin DMX output connector, you will need to use a 5 pin to 3 pin adapter. CHAUVET Model No: DMX5M.

The chart below details a proper cable conversion:

#### 3 PIN TO 5 PIN CONVERSION CHART

| CONDUCTOR        | 3 Pin Female (output) | 5 Pin Male (Input) |
|------------------|-----------------------|--------------------|
| GROUND/SHIELD    | Pin 1                 | Pin 1              |
| DATA ( - )SIGNAL | Pin 2                 | Pin 2              |
| DATA (+) SIGNAL  | Pin 3                 | Pin 3              |
| Do NOT USE       |                       | Do not use         |
| Do NOT USE       |                       | Do not use         |

# **DMX Quick Reference Chart**

|    | DMX Address Quick Reference Chart |             |      |    |    |    |    |    |     |     |     |     |     |     |     |     |     |     |     |     |     |
|----|-----------------------------------|-------------|------|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|    | Dip Switch Position               |             |      |    |    |    |    |    |     |     |     |     |     |     |     |     |     |     |     |     |     |
| DN | /IX D                             | IP S<br>SET |      | CH | #9 | 0  | 0  | 0  | 0   | 0   | 0   | 0   | 0   | 1   | 1   | 1   | 1   | 1   | 1   | 1   | 1   |
|    | 0                                 | =OF         | F    |    | #8 | 0  | 0  | 0  | 0   | 1   | 1   | 1   | 1   | 0   | 0   | 0   | 0   | 1   | 1   | 1   | 1   |
|    | 1                                 | 1O=         | 1    |    | #7 | 0  | 0  | 1  | 1   | 0   | 0   | 1   | 1   | 0   | 0   | 1   | 1   | 0   | 0   | 1   | 1   |
|    | X=O                               | FF o        | r ON | l  | #6 | 0  | 1  | 0  | 1   | 0   | 1   | 0   | 1   | 0   | 1   | 0   | 1   | 0   | 1   | 0   | 1   |
| #1 | #2                                | #3          | #4   | #5 |    |    |    |    |     |     |     |     |     |     |     |     |     |     |     |     |     |
| 0  | 0                                 | 0           | 0    | 0  |    |    | 32 | 64 | 96  | 128 | 160 | 192 | 224 | 256 | 288 | 320 | 352 | 384 | 416 | 448 | 480 |
| 1  | 0                                 | 0           | 0    | 0  |    | 1  | 33 | 65 | 97  | 129 | 161 | 193 | 225 | 257 | 289 | 321 | 353 | 385 | 417 | 449 | 481 |
| 0  | 1                                 | 0           | 0    | 0  |    | 2  | 34 | 66 | 98  | 130 | 162 | 194 | 226 | 258 | 290 | 322 | 354 | 386 | 418 | 450 | 482 |
| 1  | 1                                 | 0           | 0    | 0  |    | 3  | 35 | 67 | 99  | 131 | 163 | 195 | 227 | 259 | 291 | 323 | 355 | 387 | 419 | 451 | 483 |
| 0  | 0                                 | 1           | 0    | 0  |    | 4  | 36 | 68 | 100 | 132 | 164 | 196 | 228 | 260 | 292 | 324 | 356 | 388 | 420 | 452 | 484 |
| 1  | 0                                 | 1           | 0    | 0  |    | 5  | 37 | 69 | 101 | 133 | 165 | 197 | 229 | 261 | 293 | 325 | 357 | 389 | 421 | 453 | 485 |
| 0  | 1                                 | 1           | 0    | 0  |    | 6  | 38 | 70 | 102 | 134 | 166 | 198 | 230 | 262 | 294 | 326 | 358 | 390 | 422 | 454 | 486 |
| 1  | 1                                 | 1           | 0    | 0  |    | 7  | 39 | 71 | 103 | 135 | 167 | 199 | 231 | 263 | 295 | 327 | 359 | 391 | 423 | 455 | 487 |
| 0  | 0                                 | 0           | 1    | 0  |    | 8  | 40 | 72 | 104 | 136 | 168 | 200 | 232 | 264 | 296 | 328 | 360 | 392 | 424 | 456 | 488 |
| 1  | 0                                 | 0           | 1    | 0  |    | 9  | 41 | 73 | 105 | 137 | 169 | 201 | 233 | 265 | 297 | 329 | 361 | 393 | 425 | 457 | 489 |
| 0  | 1                                 | 0           | 1    | 0  |    | 10 | 42 | 74 | 106 | 138 | 170 | 202 | 234 | 266 | 298 | 330 | 362 | 394 | 426 | 458 | 490 |
| 1  | 1                                 | 0           | 1    | 0  |    | 11 | 43 | 75 | 107 | 139 | 171 | 203 | 235 | 267 | 299 | 331 | 363 | 395 | 427 | 459 | 491 |
| 0  | 0                                 | 1           | 1    | 0  |    | 12 | 44 | 76 | 108 | 140 | 172 | 204 | 236 | 268 | 300 | 332 | 364 | 396 | 428 | 460 | 492 |
| 1  | 0                                 | 1           | 1    | 0  |    | 13 | 45 | 77 | 109 | 141 | 173 | 205 | 237 | 269 | 301 | 333 | 365 | 397 | 429 | 461 | 493 |
| 0  | 1                                 | 1           | 1    | 0  |    | 14 | 46 | 78 | 110 | 142 | 174 | 206 | 238 | 270 | 302 | 334 | 366 | 398 | 430 | 462 | 494 |
| 1  | 1                                 | 1           | 1    | 0  |    | 15 | 47 | 79 | 111 | 143 | 175 | 207 | 239 | 271 | 303 | 335 | 367 | 399 | 431 | 463 | 495 |
| 0  | 0                                 | 0           | 0    | 1  |    | 16 | 48 | 80 | 112 | 144 | 176 | 208 | 240 | 272 | 304 | 336 | 368 | 400 | 432 | 464 | 496 |
| 1  | 0                                 | 0           | 0    | 1  |    | 17 | 49 | 81 | 113 | 145 | 177 | 209 | 241 | 273 | 305 | 337 | 369 | 401 | 433 | 465 | 497 |
| 0  | 1                                 | 0           | 0    | 1  |    | 18 | 50 | 82 | 114 | 146 | 178 | 210 | 242 | 274 | 306 | 338 | 370 | 402 | 434 | 466 | 498 |
| 1  | 1                                 | 0           | 0    | 1  |    | 19 | 51 | 83 | 115 | 147 | 179 | 211 | 243 | 275 | 307 | 339 | 371 | 403 | 435 | 467 | 499 |
| 0  | 0                                 | 1           | 0    | 1  |    | 20 | 52 | 84 | 116 | 148 | 180 | 212 | 244 | 276 | 308 | 340 | 372 | 404 | 436 | 468 | 500 |
| 1  | 0                                 | 1           | 0    | 1  |    | 21 | 53 | 85 | 117 | 149 | 181 | 213 | 245 | 277 | 309 | 341 | 373 | 405 | 437 | 469 | 501 |
| 0  | 1                                 | 1           | 0    | 1  |    | 22 | 54 | 86 | 118 | 150 | 182 | 214 | 246 | 278 | 310 | 342 | 374 | 406 | 438 | 470 | 502 |
| 1  | 1                                 | 1           | 0    | 1  |    | 23 | 55 | 87 | 119 | 151 | 183 | 215 | 247 | 279 | 311 | 343 | 375 | 407 | 439 | 471 | 503 |
| 0  | 0                                 | 0           | 1    | 1  |    | 24 | 56 | 88 | 120 | 152 | 184 | 216 | 248 | 280 | 312 | 344 | 376 | 408 | 440 | 472 | 504 |
| 1  | 0                                 | 0           | 1    | 1  |    | 25 | 57 | 89 | 121 | 153 | 185 | 217 | 249 | 281 | 313 | 345 | 377 | 409 | 441 | 473 | 505 |
| 0  | 1                                 | 0           | 1    | 1  |    | 26 | 58 | 90 | 122 | 154 | 186 | 218 | 250 | 282 | 314 | 346 | 378 | 410 | 442 | 474 | 506 |
| 1  | 1                                 | 0           | 1    | 1  |    | 27 | 59 | 91 | 123 | 155 | 187 | 219 | 251 | 283 | 315 | 347 | 379 | 411 | 443 | 475 | 507 |
| 0  | 0                                 | 1           | 1    | 1  |    | 28 | 60 | 92 | 124 | 156 | 188 | 220 | 252 | 284 | 316 | 348 | 380 | 412 | 444 | 476 | 508 |
| 1  | 0                                 | 1           | 1    | 1  |    | 29 | 61 | 93 | 125 | 157 | 189 | 221 | 253 | 285 | 317 | 349 | 381 | 413 | 445 | 477 | 509 |
| 0  | 1                                 | 1           | 1    | 1  |    | 30 | 62 | 94 | 126 | 158 | 190 | 222 | 254 | 286 | 318 | 350 | 382 | 414 | 446 | 478 | 510 |
| 1  | 1                                 | 1           | 1    | 1  |    | 31 | 63 | 95 | 127 | 159 | 191 | 223 | 255 | 287 | 319 | 351 | 383 | 415 | 447 | 479 | 511 |

Dip Switch Position

DMX Address

| Channel | Value  | Function  |
|---------|--|---|
| 1       | 000 ⇔ 010<br>011 ⇔ 120<br>121 ⇔ 250<br>251 ⇔ 255 | Mode Laser off Dynamic Patterns Static Patterns Sound Active Mode |
| 2       | 000 ⇔ 255  | Pattern Selection<br>Static Patterns – Dynamic Patterns           |
| 3       | 000 ⇔ 255  | X Position<br>Left > Right  |
| 4       | 000 ⇔ 255  | Y Position<br>Top > Bottom  |
| 5       | 000 ⇔ 255  | Scan Speed<br>Fast > Slow   |
| 6       | 000 ⇔ 255  | Dynamic Pattern Speed Control<br>Fast > Slow / See page 16        |
| 7       | 000 ⇔ 255  | Static Pattern Size Control<br>Small > Big / See page 17          |
| 8       | 000 ⇔ 100<br>101 ⇔ 200<br>201 ⇔ 255              | Color<br>Green & Red ON<br>Green<br>Red                           |
| NOTES   | Some Static patterns                             | can adjust both in size and position.                             |

CAUTION: Use of controls, adjustments, or performance of procedures other than what is specified herein may result in hazardous radiation exposure

### **Trouble Shooting**

- If the power supply indicator does not light up and the laser does not work, please check if the power supply and the corresponding parts have the right input electric current.
- 2) If it is in stand-alone mode operation, the power supply indicator is lit and the laser is not working, please check if the operation system is set up in Master/Slave mode.
- 3) If it is in Master/Slave mode, Slave mode is exceptional, please check as below:
  - A. Make sure to set up Master mode for just one unit and the others are set in slave mode.
  - B. Make sure to control the unit with DMX controller.
  - C. Make sure to take a good quality power cord and connection.
- 4) If the unit is in DMX mode, the laser cannot be controlled by the DMX controller, and the DMX signal indicator is not illuminated please check as below:
  - A. Make sure to set up the DMX mode.
  - B. Make sure to have a good connection.
- 5) If it is in DMX mode, the laser is cannot be controlled by the DMX controller but the DMX signal indicator flashes, please make sure the DMX controller and the laser have the same DMX Address.
- 6) If the no laser outputs from the projector please restart the AC power by turning off the AC switch and leaving off for 15 seconds and then turning the switch back to the on position.
- 7) If the test pattern is not in the proper position restart the AC power by turning off the AC switch and leaving off for 15 seconds and then turning the switch back to the on position.

After trying the above solution you still have a problem, please contact CHAUVET.

# **Dynamic Patterns & DMX Values**

| VALUE | DYNAMIC<br>PATTERNS                | VALUE   | DYNAMIC<br>PATTERNS   | VALUE   | DYNAMIC<br>PATTERNS |
|-------|------------------------------------|---------|-----------------------|---------|---------------------|
| 0-4   | ×,                                 | 85–89   | 6767                  | 170–174 | →                   |
| 5-9   |                                    | 90–94   | 00                    | 175–179 |                     |
| 10-14 | کی در                              | 95–99   | O >+ O                | 180–184 |                     |
| 15-19 | $\leftarrow \mid \rightarrow \mid$ | 100–104 | O→←O                  | 185–189 | <b>•</b> •          |
| 20–24 | 1                                  | 105–109 | 0)0)                  | 190–194 |                     |
| 25–29 |                                    | 110-114 | 1 ~~~~                | 195–199 | 40 40               |
| 50-54 |                                    | 115–119 |                       | 200–204 | 0,0                 |
| 35–39 | \\\\\\                             | 120-124 | $\Diamond$ $\Diamond$ | 205–209 | <b>←</b> ○ ○ →      |
| 40-44 | 1                                  | 125–129 | Y, Y,                 | 210-214 | 00                  |
| 45-49 | <u> </u>                           | 130–134 | Ø S.                  | 215–219 | -                   |
| 50-54 | → ← → ←                            | 135–139 | <del></del>           | 220–224 | <b>♦</b>            |
| 55–59 | 77                                 | 140-144 | <b>*</b>              | 225–229 |                     |
| 60-64 | Y)Y)                               | 145–149 | ←                     | 230–234 | ζ····               |
| 65–69 | <u>J</u> <u>J</u>                  | 150–154 | ***) ***-)            | 235–239 | ÓÒ                  |
| 70-74 |                                    | 155–159 | 1                     | 240–244 | Ø 8.                |
| 75–79 |                                    | 160–164 | <b>→ →</b>            | 245–249 |                     |
| 80-84 | 00                                 | 165–169 |                       | 250–254 | 77 77               |

# **Static Patterns & DMX Values**

| VALUE | STATIC<br>PATTERNS                       | VALUE   | STATIC<br>PATTERNS  | VALUE                | STATIC<br>PATTERNS |
|-------|--|---------|---------------------|----------------------|--------------------|
| 0-5   | •••                                      | 90-95   | $\Diamond \Diamond$ | 180 185              |                    |
| 6 11  | i i                                      | 96 101  |                     | 186 191              |                    |
| 12 17 | / \                                      | 102 107 |                     | 192 197              | ~~~~~              |
| 18 23 | \ /                                      | 108 113 | / \                 | 198-203              | <del>M</del>       |
| 24-29 | <b>↔</b> ↔                               | 114 119 | \ /                 | 204 <sup>-</sup> 209 | 99                 |
| 30 35 | 1 1                                      | 120 125 |                     | 210 <sup>-</sup> 215 |                    |
| 36 41 | $\uparrow$ $\uparrow$                    | 126 131 | AN AN               | 2216 221             |                    |
| 42 47 | $\longleftrightarrow\longleftrightarrow$ | 132 137 | <u>A</u> A          | 222 <sup>-</sup> 227 |                    |
| 48 53 | A A                                      | 138 143 | 77                  | 228 233              |                    |
| 54 59 | W W                                      | 144 149 |                     | 234 239              | <b>\$</b> \$       |
| 60 65 | $\triangle \triangle$                    | 150 155 | $\Diamond$          | 240 245              | <b>&gt;</b> >      |
| 66 71 | $\Diamond \Diamond$                      | 156 161 | ,,,,,               | 246 251              |                    |
| 72-77 |  | 162 167 | 74                  | 252 254              | <u> </u>           |
| 78 83 |  | 168 173 | <u> </u>            |                      |                    |
| 84 89 |  | 174 179 | <b>LJH</b> J-J      |                      |                    |

#### **General Maintenance**

To maintain optimum performance and minimize wear fixtures should be cleaned frequently. Usage and environment are contributing factors in determining frequency. As a general rule, fixtures should be cleaned at least twice a month. Dust build up reduces light output performance and can cause overheating. This can lead to reduced lamp life and increased mechanical wear. Be sure to power off fixture before conducting maintenance.

Unplug fixture from power. Use a vacuum or air compressor and a soft brush to remove dust collected on external vents and internal components. Clean all glass when the fixture is cold with a mild solution of glass cleaner or Isopropyl Alcohol and a soft lint free cotton cloth or lens tissue. Apply solution to the cloth or tissue and drag dirt and grime to the outside of the lens. Gently polish optical surfaces until they are free of haze and lint.

The cleaning of internal and external optical lenses and/or mirrors must be carried out periodically to optimize light output. Cleaning frequency depends on the environment in which the fixture operates: damp, smoky or particularly dirty surrounding can cause greater accumulation of dirt on the unit's optics. Clean with soft cloth using normal glass cleaning fluid. - Always dry the parts carefully. - Clean the external optics at least every 20 days. Clean the internal optics at least every 30/60 days.

#### **Returns Procedure**

Returned merchandise must be sent prepaid and in the original packing, call tags will not be issued. Package must be clearly labeled with a Return Merchandise Authorization Number (RA #). Products returned without an RA # will be refused. Call CHAUVET and request RA # prior to shipping the fixture. Be prepared to provide the model number, serial number and a brief description of the cause for the return. Be sure to properly pack fixture, any shipping damage resulting from inadequate packaging is the customer's responsibility. CHAUVET reserves the right to use its own discretion to repair or replace product(s). As a suggestion, proper UPS packing or double-boxing is always a safe method to use.

### **Claims**

Damage incurred in shipping is the responsibility of the shipper; therefore the damage must be reported to the carrier upon receipt of merchandise. It is the customer's responsibility to notify and submit claims with the shipper in the event that a fixture is damaged due to shipping. Any other claim for items such as missing component/part, damage not related to shipping, and concealed damage, must be made within seven (7) days of receiving merchandise.

# **Technical Specifications**

| WEIGHT & DIMENSIONS              |  |
|----------------------------------|--|
| Length                           |  |
|                                  |  |
| Height                           | 130 mm (5.12 in)                       |
|                                  |  |
| 3 3                              | 3 (* * * * *)                          |
| POWER                            |  |
| Switch-selectable power settings | 120V 60Hz AC or 230V 50Hz              |
|                                  | 2A 250V                                |
| Current draw                     | (peak 25W @ 120V), (peak 25W @ 230V)   |
|                                  | ······································ |
| LASER                            |  |
| Rated power                      | 20W                                    |
|                                  | 1 x 10mW green laser                   |
|                                  | 1 x 10mW red laser                     |
|                                  | 532 nm & 650 nm                        |
| Pan                              | 97°                                    |
|                                  |  |
|                                  |  |
|                                  | DPSS                                   |
|                                  | Dual <20mW                             |
|                                  | Fan Cooled                             |
| Cooming                          | T ari oolida                           |
| CONTROL & PROGRAMMING            |  |
|                                  | locking 3-pin XLR male socket          |
| Data niput                       | locking 3-pin XLR female socket        |
|                                  | pin 1 shield, pin 2 (-), pin 3 (+)     |
|                                  | DMX-512 USITT                          |
|                                  |  |
| DIVIA CHAILIEIS                  |  |
|                                  |  |
| ORDERING INFORMATION             |  |
|                                  | LRG-55                                 |
| 3601p1011 - 33 KG                | LRG-55                                 |

# **Technical Support**

Address: Service Dept.

3000 N 29th Ct, Hollywood, FL 33020 (U.S.A.) Support (Email): tech@chauvetlighting.com Telephone: (954) 929-1115 - (Press 4) Fax: (954) 929-5560 - (Attention: Service) Website: http://www.chauvetlighting.com